


Size: 192x180mm

注意: 折叠后尺寸为48x90mm



USER MANUAL



1700 Lumen Rifle Flashlight

FL-OSP-1700

Picatinny or M-LOK
www.ospreyscopes.com
sales@ospreyscopes.com

SPECIFICATIONS



4.9 ft



IPX6



70 min



918 ft



4.9 oz




5.51x1.33x1.22 in




White light 1700 Lumens

PRODUCT OVERVIEW

Mounting Accessory Type 2



01



Mounting Accessory Type 1

Product Features

The flashlight features USB-C charging and a dual-switch design, making operation simple and convenient. It supports two mounting methods and is compatible with Picatinny and M-LOK rail systems, allowing installation on a variety of devices.

- Modes: Strong / Flash

Type-C Charging

02

This flashlight uses a Type-C charging port with a reversible connector for convenient and fast charging. The indicator light is red while charging and green when fully charged.

Modes of Operation

- Press the switch once to turn on high mode.
- Press the switch twice quickly to activate strobe mode.

Note: Each press must be within 0.5 seconds of the previous press for the mode change to register.

Tactical Mode

Press and hold the switch to activate the tactical light. Release the switch to turn the light off.

Note: This function operates with the constant white LED only.

03

Installation Instructions

Picatinny rail Mounting Instructions:

- Remove the pre-installed M-LOK mounting components from the flashlight assembly.
- Loosen the screws on the Picatinny mount to allow the mount to open fully.
- Place the flashlight onto the Picatinny rail in the desired position on the firearm.
- Tighten the mounting screws evenly and securely to ensure a stable attachment.
- Confirm that the flashlight is properly seated on the rail and does not shift or move.
- Verify proper installation and function before operating the firearm.

M-LOK Mounting Instructions:

- Using the provided Allen wrench, remove the four screws securing the pre-installed Picatinny mounting

04

components to the flashlight assembly.

- Loosen the M-LOK mounting screws with the provided Allen wrench until the M-LOK locking tabs can move freely.
- Position the flashlight on the desired M-LOK slot location on the firearm handguard.
- Ensure the M-LOK locking tabs are fully inserted into the slots before tightening.
- Tighten the mounting screws evenly with the Allen wrench until the locking tabs rotate to a 90-degree position and securely clamp the flashlight to the handguard.
- Confirm that the flashlight is firmly mounted and does not shift or move.
- Verify proper installation and function before operating the firearm.

05

IN THE BOX

- 1 x Flashlight
- 2 x Nuts
- 2 x Screws
- 2 x Small Wrenches
- 1 x USB-C Charging Cable
- 1 x User Manual

06

WARNING

- Do not shine the flashlight directly into anyone's eyes. It may cause temporary blindness or permanent eye damage.
- Do not cover the flashlight head while it is on, or place the light face-down on a surface. The heat generated may damage the flashlight or cause nearby materials to burn.
- Do not use rechargeable lithium batteries without a protection circuit. Doing so may lead to battery damage or other safety hazards.
- Do not leave the flashlight in a fabric bag or flammable plastic container while it is on or still hot, as the high temperature may cause damage or create a fire risk.



Made In China